

TWAL Sequence TWT Amplifier

Datasheet



Model No.	Frequency Range	Power Range (Watt)
TWAL 0103	1 ... 2.5 GHz	
TWAL 0118	1 ... 18 GHz	20~30
TWAL 0204	2 ... 4 GHz	250
TWAL 0206	2 ... 6 GHz	200
TWAL 0208	2 ... 8 GHz	
TWAL 0408	4 ... 8 GHz	
TWAL 0410	4 ... 10 GHz	70~170
TWAL 0412	4 ... 12 GHz	20
TWAL 0418	4 ... 18 GHz	
TWAL 0618	6 ... 18 GHz	1500
TWAL 0810	8 ... 10 GHz	
TWAL 0812	8 ... 12 GHz	
TWAL 0818	8 ... 18 GHz	
TWAL 1012	10 ... 12 GHz	1000

TWAL 1218	12 ... 18 GHz	20
TWAL 1823	18 ... 23 GHz	200
TWAL 1826	18 ... 26.5 GHz	40~120
TWAL 1840	18 ... 40 GHz	40
TWAL 2640	26 ... 40 GHz	40~120
TWAL 2731	27 ... 31 GHz	100



SUZHOU 3CTEST ELECTRONIC CO., LTD.

Add.: No. 99 E'meishan Road, SND, Suzhou, Jiangsu Province, China

Tel: +86 (0)512 6807 7192 Fax: +86-512-68079795

Sales Email: globalsales@3ctest.cn Service Email: service@3ctest.cn

www.3c-test.com